





MyKronoz Watch Face Store

- GETTING STARDED -






UPLOAD YOUR OWN WATCH FACE TO THE MYKRONOZ WATCH FACE STORE (WEBSITE)



1. Go to <https://watchfaces.mykronoz.com/> and login with your MyKronoz account
2. Login with your MyKronoz account.
Any other email address not associated with a MyKronoz account will be declined.
3. Once logged in, click on the  icon to upload your creation.
4. Then click on the  icon to select your file.
5. Adjust your watch face and click on OK.
6. Add a title and a quick description to your creation and click on  .
Feel free to add tags so that your creations are gathered under the same theme. This will help other users in their search.
7. Your creation will be directly sent for approval.
This operation can take up to 24 hours.
8. If your creation is approved, it will appear directly in the MyKronoz Watch Face store.


DOWNLOAD A WATCH FACE FROM THE MYKRONOZ WATCH FACE STORE (MOBILE APP)






1. Open the MyKronoz Mobile App and click on the Watch Faces Tab.
2. Click on the Watch face store and select your desired watch face.
3. Click on the  icon to download the watch face.
4. Click on  to confirm.

Once you have downloaded a watch face, you can view it from your phone library.

INSTALL A WATCH FACE FROM THE MYKRONOZ WATCH FACE STORE (MOBILE APP)



1. Go back to the **Watch Face Tab** and click on **My Creations**.
2. Click on **Add a watch face** and tap on **Photo**.
3. Select your downloaded watch face by clicking on the **From Library** section.
4. Select your desired watch face and adjust the size. Click on  to confirm.
5. Add some widgets if you wish. Click on  to save.
6. Click on your desired watch face to store it on the watch. Click on  to confirm.
7. This procedure can take up to 1-2 minutes.

Only 4 watch faces can be installed on your watch and 10 watch faces can be saved in The MyKronoz App. If the storage is not sufficient for new watch faces, make sure to delete one and replace it with the new one. Otherwise, your new watch face will automatically replace the oldest one. To delete a stored watch face, long press the watch face that you want to delete from the stored in my watch section and click on **X** to confirm.

WATCH FACE CREATOR

Enjoy endless customization possibilities, designed to match your style and tastes. Choose among multiple options to personalize your own watch face: new complications layouts, multiple watch dials, wide range of colors, digital second hands, additional widgets and more!

